

W24 0 / W24 P +12V
W16 0 / W16 P GND
W8 0 / W8 P -12V
IN / EXT_IN

W27 0 / W27 P
W19 0 / W19 P
W11 0 / W11 P
W3 0 / W3 P

W26 0 / W26 P
W18 0 / W18 P
W10 0 / W10 P
W2 0 / W2 P

W25 0 / W25 P
W17 0 / W17 P
W9 0 / W9 P
W1 0 / W1 P

